


# Installation Manual

**PAGEONE**  
lighting

ITEM NO: PT141063

Figure No 1: Unpack the box: Check the contents of the box for the following items below.

Figure N° 1



## CAUTION:

1. "Suitable for dry locations only"

How to turn on/off the light fixture:

1. Lightly press and hold for 2 seconds to turn the light off .
2. Lightly press the dimmer switch to turn the fixture back on.

How to dim:

1. Turn on the light/100% brightness

↓  
2. 50% Brightness

↓  
3. 15% Brightness

↓  
4. 5% Brightness

↓  
5. Turn off

